

SOJAG


produits saisonniers • seasonal products




Sojag code : 999-8163124


CUP/UPC code : 772830163124

Assembly Manual / Guide d'assemblage / Manual de ensamblaje / 조립설명서 / Montageanleitung






Use the hex keys in the box. / Utilisez les clés hexagonales fournies dans la boîte. / Utilice las llaves hexagonales en la caja. / 상자에 육각 키를 사용 하십시오. / Verwenden Sie die Sechskantschlüssel in der Box.



Please use a Phillips screwdriver. / Utilisez un tournevis de type Phillips / Por favor, use un destornillador Phillips. / 십자 드라이버를 사용 하십시오. / Bitte verwenden Sie einen Kreuzschraubenzieher.



You may need to use a drill for this step. / Vous pouvez avoir besoin d'utiliser une perceuse pour cette étape. / Puede que tenga que utilizar un taladro para este paso. / 이 단계에선 드릴을 사용해야 할 수도 있습니다. / Für diesen Schritt können Sie einen Bohrer verwenden.



Wearing protective gloves is recommended. / Le port de gants de protection est recommandé / El uso de guantes de protección se recomienda. / 보호 장갑을 착용 하는 것이 좋습니다. / Das Tragen von Schutzhandschuhen wird empfohlen.



Two or more people are required at this stage. / Deux personnes ou plus sont nécessaires à cette étape. / Dos o más personas se requieren en esta etapa. / 이 단계에서는 두 명 이상 이 필요합니다. / Für diesen Bauschritt sind 2 oder mehr Personen erforderlich.




Do not tighten screws all the way for now. / Ne pas visser fermement pour l'instant. / No atornille con firmeza por ahora. / 아직 나사를 단단히 조이지 마십시오. / Bitte die Schrauben zum jetzigen Zeitpunkt noch nicht fest anziehen.




Sold separately. / Vendus séparément. / vendido en las opciones. / 옵션 판매 / Optional erhältlich


U X 17 (+3)




U1 X 20 (+5)




U2 X 2 (+1)




V X 88 (+10)




V1 X 52 (+5)




V2 X 8 (+2)




X X 16 (+2)




Y X 80 (+8)




Y1 X 54 (+5)

























Z X 1


















Z1 X 1







A X4	B X2	
		
B1 X2	C X2	
		
C1 X2	D X2	
		
D1 X2	E X4	
		
E1 X4	E2 X4	
		
F X2	F0 X4	
		
F1 X6	F2 X6	G X8
		
H X4	I X20	
		




J X4 	J1 X4 	
J2 X2 	K X1 	
K1 X1 	L1 X4 	
L2 X4 	M1 X4 	
M2 X4 	M3 X6 	M4 X4 
R X6 	Q X4 	
W X4 	W1 X4 	



























































12A/19






















Ix18



Yx36









Clemens **HobbyTec**

**NOCH FRAGEN RUND
UM DAS PRODUKT
ODER ZUM AUFBAU?**

RUFEN SIE UNS AN:
+49 (0) 6571 929 222

SERVICE@CLEMENS-HOBBYTEC.DE

CLEMENS HOBBYTEC GMBH
RUDOLF-DIESEL-STRASSE 8
D-54516 WITTLICH

WWW.CLEMENS-HOBBYTEC.DE