



# Classic Soccer Rebounder

88 cms X 88 cms

## USER MANUAL



### WARNING

THE PRODUCT IS TO BE  
ASSEMBLED BY AN ADULT.



### WARNING

Potential hazard description, e.g. In  
unassembled state contain potentially  
hazardous sharp points, so please  
keep out of child's reach



# Classic Soccer Rebounder


88 cms X 88 cms

## CONTENT

1



1 PC



## ASSEMBLY

1. Take the rebounder out of the package.
2. Place the rebounder on a level surface (fig. 1).
3. Lift the front frame with net upwards (fig. 2 & 3).
4. Slide the pipe that is connected to the bottom of the front frame into the pipe that is connected to the base of the frame (fig. 4).
5. Slide the pipe to the desired angle & tighten the knob to fix the angle (fig. 5 & 6).
6. Your rebounder is now ready to use.





# Classic Soccer Rebounder

88 cms X 88 cms



## CHANGING ANGLE

1. Loosen the knob at the back of the rebounder (fig.7).
2. Slide the steel pipe up / down to reach your desired angle (fig.8).
3. When the desired angle is reached, tighten the knob again to secure the rebounder (fig.9).
4. The angle of your rebounder has now been changed.



## STORAGE & TRANSPORT

1. Store the rebounder after each use.
2. Loosen the knob on the white pipe (fig.10) and slide the steel pipe out of the white pipe (fig. 11) and fold both pipes to the net.
3. Lower the front frame with the net towards the ground (fig.12).
4. You can now move and/or store your rebounder. Use the bottom frame as a handle (fig.13).





# Classic Soccer Rebounder

## 88 cms X 88 cms

### WARNING

1. This rebounder is made from Steel. Do NOT leave the rebounder outside after use because moisture will lower the life of the rebounder. Avoid bringing the rebounder in contact with water, moisture or dampness of any kind.
2. Store in a cool and dry place.
3. Do NOT leave the rebounder unnecessarily exposed to UV rays and direct sunlight.
4. Children under 10 years of age must only assemble under the supervision of an adult.
5. Please keep small children away from the net to reduce risk of entanglement. Do not let children climb on the rebounder. Exercise caution while using the rebounder when small children are around! The manufacturer or the seller are not liable for any complications arising from the misuse of this product.

### CLEANING

1. Do NOT wash the rebounder. Only wipe clean with a dry cloth.
2. Avoid contact with any corrosive liquids or substances such as water, salt water, fuel, kerosene, etc. at all times. Oils and such chemicals can damage the net and reduce their life significantly.

### TRANSPORT AND STORAGE

1. The rebounder is best moved in the folded position as delivered. Should you want to move the rebounder in assembled/upright position, please move with two people to spread weight and reduce risk of injury.
2. Store in a cool and dry place, away from sunlight and dampness. Damp environment may lead to development of mould on the net.