

MULMSAUGER & WASSERSAUGER


Entfernt Schmutz vom Boden des Aquariums und kann auch zum Wasserwechsel verwendet werden

- Inkl. 4 x Filterbeutel und Schlauch
- Verstellbares Teleskoprohr
- Wassertiefe von 20 bis 60 cm für kleine und große Aquarien
- Durchfluss 520 l/h
- Arbeitet mit zwei Batterien (C/LR14, nicht im Lieferumfang)


Achtung: Nicht außerhalb des Wassers verwenden und immer im Bereich der Min-Max-Markierung



Bodengrund reinigen



Wasser ablassen



Reinigen bei niedrigem Wasserstand



GRAVEL VACUUM CLEANER & WATER-EXTRACTION SYSTEM

Remove dirt from the bottom of the aquarium and can also be used to change the water

- Incl. 4 x filter bags and a hose
- Adjustable telescopic tube
- Works at depth of 20 to 60 cm for small and large aquariums
- Flow rate 520 l/h
- Requires two batteries C/LR14 (not included in the scope of delivery)

Warning: Do not use out of water and always use in areas that are within the range of the min/max markings



1. An/Aus
2. Haltebügel
3. Wasserniveau Min/Max-Markierung
4. Anschluss Filterbeutel/Schlauch
5. Teleskoprohr
6. Kies/Sandreiniger



1. On/Off
2. Holding bracket
3. Min / max water level markings
4. Filter bag/hose connection
5. Telescopic tube
6. Gravel / sand cleaner