



# Einhell

## EXPERT PLUS



Cordless Leaf Blower

**GE-CL 18/1 Li E-Solo**

**Item No.: 3433541**

Ident No.: 21010

Bar Code: 4006825651645

The GE-CL 18/1 Li E-Solo cordless universal blower is ideal for blowing leaves, grass clippings and other dirt and debris from courtyards, driveways, footpaths, garages, terraces and outdoor furniture. The handy size and low weight enable very user-friendly operation. The split tube allows for easy cleaning of outdoor furniture in confined spaces while the full-length tube makes quick work of paths and driveways. Thanks to the detachable tube the storage of the blower is also space-saving. Additionally the electronic speed control allows the user to vary the air speed to suit the application while the soft grip handle provides added comfort during use.

This product comes without a battery and without charger which are available separately.

## Features & Benefits

- Low weight and easy handling
- 2-parts tube for universal operation around house and garden
- Electronic speed control
- Softgrip for user-friendly operation
- Strong blow velocity with 210 km/h
- Supplied without battery and charger (available separately)



## Technical Data

- No-load speed ( idle speed ) 12000 min<sup>-1</sup>
- Blow velocity 210 km/h
- Max. air volume 105 m<sup>3</sup>/h

## Logistic Data

- Product weight 1.33 kg
- Gross weight single packaging 1.91 kg
- Dimensions single packaging 490 x 155 x 182 mm
- Pieces per export carton 8 Pieces
- Gross weight export carton 15.62 kg
- Dimensions export carton 635 x 505 x 385 mm
- Container quantity (20"/40"/40"HC) 1600 | 3280 | 3936



## Available as special accessories



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



2x 3,0Ah & Twincharger Kit  
PXC-Starter-Kit  
Item No.: 4512083  
Bar Code: 4006825638509  
Einhell Accessory



18V 3,0Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



2x 3,0Ah & 30min PXC Kit  
PXC-Starter-Kit  
Item No.: 4512098  
Bar Code: 4006825646986  
Einhell Accessory



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 4,0Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 3,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512041  
Bar Code: 4006825613698  
Einhell Accessory



18V 4,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



18V 2,5Ah Power X-Change  
Battery  
Item No.: 4511516  
Bar Code: 4006825650518  
Einhell Accessory





18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory

## Battery-Running-Times

One Battery for All	 blowing <sup>1</sup>	 blowing <sup>2</sup>
	(min.)	(min.)
1.5 Ah	180	10
2.0 Ah	240	14
2.5 Ah	300	16
3.0 Ah	390	20
4.0 Ah	480	26
5.2 Ah	660	40
6.0 Ah	720	42

### Test setup:

1) Min. electronic speed

2) Max. electronic speed